

AXIS Speaker Functionality for Singlewire InformaCast®

AXIS Speaker Functionality for Singlewire InformaCast®

Table of Contents

About application	3
Add your device in AXIS Device Manager	4
Secure passwords	4
Install and license all the application	5
Edit the .csv file	5
Add the application to the device	5
Contact support	7

AXIS Speaker Functionality for Singlewire InformaCast®

About application

About application

Singlewire InformaCast® is a single platform that allows you to send out emergency messages and other communication with the technology your organization already has in place, including Axis network speakers. InformaCast mass notification system delivers intrusive and attention-getting audio alerts throughout your facility. AXIS Speaker Functionality for Singlewire InformaCast allows you to connect your Axis devices to your Singlewire InformaCast infrastructure. The application can be used on Axis network speakers after you purchase a license and install the application through AXIS Device Manager.

AXIS Speaker Functionality for Singlewire InformaCast®

Add your device in AXIS Device Manager

Add your device in AXIS Device Manager

1. Run AXIS Device Manager Client.
 - To download and install AXIS Device Manager, go to axis.com/products/axis-device-manager.
2. When AXIS Device Manager starts, it automatically searches for devices.
 - 2.1 To manually search, click  .
 - 2.2 If no devices are found, do an inspection of your network configuration.
 - 2.3 If the application informs you that some devices have old firmware, click the link to upgrade to the latest firmware.
 - 2.4 Select the devices you want to add, click **Next**, and then click **Finish**.
3. Set a password for the devices:
 - 3.1 Select all your devices and click  .
 - 3.2 Enter username and password, and click **OK**.

Secure passwords

Important

Axis devices send the initially set password in clear text over the network. To protect your device after the first login, set up a secure and encrypted HTTPS connection and then change the password.

The device password is the primary protection for your data and services. Axis devices do not impose a password policy as they may be used in various types of installations.

To protect your data we strongly recommend that you:

- Use a password with at least 8 characters, preferably created by a password generator.
- Don't expose the password.
- Change the password at a recurring interval, at least once a year.

AXIS Speaker Functionality for Singlewire InformaCast®

Install and license all the application

Install and license all the application

1. In AXIS Device Manager, click  to create a system report.
2. Open the .csv in a program other than Microsoft® Excel®.
3. *Edit the .csv file on page 5.*
4. Go to license key registration to generate keys from the license code. Go to .
5. Upload the .csv file from AXIS Device Manager.
The system generates license keys that you can download.
6. To download the license keys, click **Download the result as zip**.
7. Extract the .zip file.
8. Download AXIS Speaker Functionality for Singlewire InformaCast for your device from .
9. *Add the application to the device on page 5.*
10. Go to the InformaCast portal to control that the devices were added.

Edit the .csv file

1. Remove all data except for the MAC address on the devices you want to license.
2. Enter 'code' and 'device' in the first row. The format must be `code,device`.
3. Enter the license code and the MAC address on the following rows. The format must be `license code,MAC address`.

Note

There is one MAC address on each row of the document.

Example:

row 1: `code,device`

row 2: `ABC1D-23EFG-H4IJ5-KL6MN,ABC0123DEFA4`

row 3: `ABC1D-23EFG-H4IJ5-KL67M,ABC123DE4FAB`

Add the application to the device

1. Select your devices.
2. Click .
3. Click **Browse** to find and select the downloaded application.
4. Click **Next**.
5. When asked to install the application, select **Yes** and click **Next**.
6. Click **Browse** to find the license key file. Select the license key files for your selected devices. The connected MAC address is in the file name.

AXIS Speaker Functionality for Singlewire InformaCast®

Install and license all the application

7. Click Next and Finish.
8. Redo if you want to set up other device models.

AXIS Speaker Functionality for Singlewire InformaCast®

Contact support

Contact support

If you need more help, go to axis.com/support.

